

# Instructions P6460 DATA ACQUISITION PROBE



P6460 data acquisition probe.

#### INTRODUCTION

The P6460 is a 100 MHz data acquisition probe suitable for use with the 1240/1241 Logic Analyzer 1240D1 and 1240D2 Acquisition Cards and the DAS 91A24 and 91AE24 Data Acquisition Modules. The P6460 has nine data channels and a clock line. When used with the DAS, one of the data channels serves as a clock qualifier.

The P6460 probe can also be used with the following DAS modules:

91S16/32 Pattern Generation Module 92A16/16E Data Acquisition Module 92S16/32 Pattern Generation Module

These Instructions contain the service information for this probe. For convenience, put a copy of them in the back of the

service manual for the logic analyzer that the probe will usually be used with.

4345-1

#### Labels

Two labels are included with your probe. The one with an 8 in the upper left corner and a C/Q in the upper right corner is for use with 1240/1241 Logic Analyzer. The label with a Q in the upper left corner and a CK in the upper right corner is for use with DAS91A24 and 91AE24 Data Aquisition Modules.

#### **Operator's Information**

This manual contains primarily service information. For operator's information, refer to the operator's manual of the instrument that the probe is to be used with, either the 1240/1241 Logic Analyzer Operator's Manual or the DAS 9100 Series Operator's Manual.

070-4345-00 Product Group 57/5E Copyright © 1983, 1987, Tektronix, Inc. All rights reserved.

FIRST PRINTING JANUARY 1983 REVISED PRINTING DECEMBER 1987

#### **ACCESSORIES**

#### Standard Accessories:

1 Instruction Sheet	070-4345-00
1 Lead Set, 10 inch	012-0747-00
1 Package of 12 Probe Tips	
(each tip is a 206-0222-00)	020-1386-00
2 Ground (or VL) Sense Leads, 5 inch.	
with Pomona Hook Tips (344-0267-00)	012-0989-00
2 Alligator Clips (substitute for hook	
tips above)	344-0046-00

When ordering the P6460 for the 92A16 use the part number 010-6460-16. This insures you will receive the appropriate standard accessories for the 92A16/16E listed below.

#### 010-6460-16 Standard Accessories:

1 Instruction Sheet	070-4345-00
1 Lead Set, 5 inch	012-0987-00
2 Ground VL Sense Leads, 5 inch with	
Pomona Hook Tips (344-0267-00)	012-0989-00
2 Alligator Clips (substitute for hook	
tips above)	344-0046-00

#### **Optional Accessories:**

. <b>.</b>	
Flying Lead Set, 5 inches long	012-0987-00
Flying Lead Set, 25 cm long	012-0800-00
40-pin Univ. Probe Intfc. Kit	020-1041-00
1240 Diagnostic Lead Set	198-5069-00
Diagnostic Lead Set, 10 inches long	012-1000-00
Package of 10 Ground (or VL) Sense	
Leads with Pomona Hook Tips	
(344-0267-00)	012-0989-01
GPIB Connector/Adapter	103-0209-00
IC Extractor, 16 pin	003-0709-00
Adapter, Test Clip, 16 DIP	015-0330-00
Adapter, Test Clip, 40 DIP, 10 cm	
cable (requires 380-0560-05 Adapter)	015-0339-02
Adapter, Test Clip, 40 DIP, 30 cm	
cable (requires 380-0560-05 Adapter)	015-0339-00
Adapter, required for use with 40 DIP	
Adapters	380-0560-05



Standard accessories for the P6460.

## GROUND CONNECTIONS AND FREQUENCY

For clock operating frequencies up to 25 MHz, the 10-inch lead sets (012-0747-00 or 012-0800-00) with one USER'S GND lead connected are sufficient.

For clock operating frequencies above 25 MHz but below 50 MHz, 10-inch lead sets may be used if both USER'S GND leads are connected.

For frequencies above 50 MHz and noisy environments, be sure to use the 5-inch lead sets (012-0987-00) and both USER'S GND leads with alligator clips.

### **SERVICE INFORMATION**

WARNING

Disconnect power before removing protective coverings, soldering, or replacing components.

#### **TEKTRONIX FIELD SERVICE**

Service of Tektronix products is available from Tektronix Service Centers around the world. Contact your local sales or service organization for more information.

#### **SPECIFICATIONS**

## Table 1 ELECTRICAL SPECIFICATIONS

Characteristic	Performance Requirements	Supplemental Information
MODULE-TO-PROBE SIGNALS  Max. Operating Power  Requirements		$+5$ V ( $\pm$ 5%) at 600 mA when 20 output lines are terminated to $+3$ V through 60 s at 300 mA when all output lines are unterminated
PROBE-TO-MODULE SIGNALS		Differential FCI
Data Channel Signal		Differential ECL Vcc = +5 V Vee = Gnd
User's Ground Sense		$<$ 100 $\Omega$ to user's ground
Input Resistance	1 MΩ ± 1%	
Input Capacitance		5 pF nominal
Max. Non-Destructive Input Voltage Range		± 40 V (DC + peak AC)
Max. Voltage Between Any Two Inputs		± 60 V (DC + peak AC)
Operating Input Voltage Range		From -40 V to input threshold's voltage + 10 V (+ 30 V for RS-232 only)
Threshold Offset and Accuracy		$\pm$ 0.25% of threshold $\pm$ 50 mV
Minimum Input Swing		0.5 V p-p centered on the threshold
Minimum Pulse Width (with input 250 mV over the threshold from + 0.5 V and - 0.5 V)		4 ns at threshold

Table 2 ENVIRONMENTAL SPECIFICATIONS

Characteristic	Description			
Temperature Operating Storage	-15°C to +55°C -62°C to +75°C			
Humidity	95% to 97% relative humidity			
Altitude Operating Non-operating	4.5 km (15,000 ft.) 15 km (50,000 ft.)			
Electrical Discharge	5 kV maximum from 200 pf with 2K $\Omega$ series resistance			

#### STATIC PRECAUTIONS



Static discharge can damage any semiconductor in this instrument.

Observe the following precautions to avoid static damage:

- 1. Minimize handling of static-sensitive components.
- Transport and store static-sensitive components or assemblies in their original containers, or on a metal rail, or on conductive foam. Label any package that contains static-sensitive components or assemblies.
- Discharge the static voltage from your body by wearing a wrist strap while handling these components. Servicing static-sensitive assemblies should be performed only in a static-free work station by qualified service personnel.

Table 3
PHYSICAL SPECIFICATIONS

Characteristic	Description			
Weight	12 oz.			
Overall Dimensions				
Pod	4.5 in. long, 2.2 in. wide, 0.85 in. deep			
Cable	78.75 in. (2 m) ± 10%			

- Nothing capable of generating or holding a static charge should be allowed on the work station surface.
- 5. Keep the component leads shorted together whenever possible.
- 6. Pick up components by the body, never by the leads.
- 7. Do not slide the components over any surface.
- Avoid handling components in areas that have a floor or work-surface covering capable of generating a static charge.
- Use a soldering iron that is connected to earth ground.
- Use only special anti-static suction type or wick type desoldering tools.

#### NOTE

Damage to electrical components may not be immediately apparent. Always follow the precautionary measures listed above when handling static-sensitive components.

#### PERFORMANCE CHECK

#### **Specification Checked**

The input resistance of each channel should be 1 M $\Omega$  ±1%.

#### Required Equipment

One digital multimeter with at least 0.2% accuracy at 1  $\text{M}\Omega.$  For example, the Tektronix DM 5010.

#### **Procedure**

1. With the probe disconnected, measure the resistance between the input to the channel you are checking and any other channel. Call this value R<sub>a</sub>.

- Next, measure the resistance between the input to the channel you want to measure and a third channel. Call this value Rb.
- 3. Finally, measure the resistance between the two other channels. Call this value  $R_{\it c}$ .
- 4. Calculate the value of the input resistance of the original channel using:

$$Rinput = \frac{Ra + Rb - Rc}{2}$$

		¥

# REPLACEABLE ELECTRICAL PARTS

#### PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order. Part number, instrument type or number, serial number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

#### LIST OF ASSEMBLIES

A list of assemblies can be found at the beginning of the Electrical Parts List. The assemblies are listed in numerical order. When the complete component number of a part is known, this list will identify the assembly in which the part is located.

## CROSS INDEX-MFR. CODE NUMBER TO MANUFACTURER


The Mfr. Code Number to Manufacturer index for the Electrical Parts List is located immediately after this page. The Cross Index provides codes, names and addresses of manufacturers of components listed in the Electrical Parts List.

#### **ABBREVIATIONS**


Abbreviations conform to American National Standard Y1.1

#### COMPONENT NUMBER (column one of the Electrical Parts List)

A numbering method has been used to identify assemblies, subassemblies and parts. Examples of this numbering method and typical expansions are illustrated by the following:



Read: Resistor 1234 of Assembly 23



Read: Resistor 1234 of Subassembly 2 of Assembly 23

Only the circuit number will appear on the diagrams and circuit board illustrations. Each diagram and circuit board illustration is clearly marked with the assembly number. Assembly numbers are also marked on the mechanical exploded views located in the Mechanical Parts List. The component number is obtained by adding the assembly number prefix to the circuit number.

The Electrical Parts List is divided and arranged by assemblies in numerical sequence (e.g., assembly A1 with its subassemblies and parts, precedes assembly A2 with its subassemblies and parts).

Chassis-mounted parts have no assembly number prefix and are located at the end of the Electrical Parts List.

## TEKTRONIX PART NO. (column two of the Electrical Parts List)

Indicates part number to be used when ordering replacement part from Tektronix.

## SERIAL/MODEL NO. (columns three and four of the Electrical Parts List)

Column three (3) indicates the serial number at which the part was first used. Column four (4) indicates the serial number at which the part was removed. No serial number entered indicates part is good for all serial numbers.

#### NAME & DESCRIPTION (column five of the Electrical Parts List)

In the Parts List, an Item Name is separated from the description by a colon (:). Because of space limitations, an Item Name may sometimes appear as incomplete. For further Item Name identification, the U.S. Federal Cataloging Handbook H6-1 can be utilized where possible.

## MFR. CODE (column six of the Electrical Parts List)

Indicates the code number of the actual manufacturer of the part. (Code to name and address cross reference can be found immediately after this page.)

#### MFR. PART NUMBER (column seven of the Electrical Parts List)

Indicates actual manufacturers part number

#### CROSS INDEX - MFR. CODE NUMBER TO MANUFACTURER

Mfr.			
Code	Manufacturer	Address	City, State, Zip Code
01121	ALLEN-BRADLEY CO	1201 SOUTH 2ND ST	MILWAUKEE WI 53204-2410
04222	AVX CERAMICS DIV OF AVX CORP	19TH AVE SOUTH	MYRTLE BEACH SC 29577
		P 0 B0X 867	
07263	FAIRCHILD SEMICONDUCTOR CORP	10400 RIDGEVIEW CT	CUPERTINO CAW CA 95014
	NORTH AMERICAN SALES		
	SUB OF SCHLUMBERGER LTD MS 118		
19701	MEPCO/CENTRALAB	P 0 B0X 760	MINERAL WELLS TX 76067-0760
	A NORTH AMERICAN PHILIPS CO		
22526	DU PONT E I DE NEMOURS AND CO INC	515 FISHING CREEK RD	NEW CUMBERLAND PA 17070-3007
	DU PONT CONNECTOR SYSTEMS		
	DIV MILITARY PRODUCTS GROUP	120001000102	
24546	CORNING GLASS WORKS	550 HIGH ST	BRADFORD PA 16701-3737
27014	NATIONAL SEMICONDUCTOR CORP	2900 SEMICONDUCTOR DR	SANTA CLARA CA 95051-0606
80009	TEKTRONIX INC	4900 S W GRIFFITH DR	BEAVERTON OR 97077
		P 0 B0X 500	
81073	GRAYHILL INC	561 HILLGROVE AVE	LA GRANGE IL 60525-5914
		PO BOX 10373	

Command No	Tektronix	Serial/Asser Effective		Name & Description	Mfr. Code	Mfr. Part No.
Component No.	Part No.	crrective	DSCOTT	CKT BOARD ASSY:MAIN	- COULE	mi. raic no.
A70				(NOT REPLACEABLE-ORDER 672-1119-01)		
A70C104	283-0186-00			CAP, FXD, CER DI:27PF, 5%, 50V	04222	SR155A 270JAA
A70C121	283-0177-00			CAP, FXD, CER DI:1UF, +80-20%, 25V	04222	SR302E105ZAATR
A70C121	283-0177-00			CAP. FXD. CER DI:1UF. +80-20%, 25V	04222	SR302E105ZAATR
A70CR115	152-0333-00			SEMICOND DVC.DI:SW,SI,55V,200MA,DO-35	07263	FDH-6012
A70J126	131-2615-00			CONN, RCPT, ELEC: CKT BD, RTANG, 17/34 CONT, MALE		65820-005
A700120	131-2013-00			COMM, NOT T, EEEC. CRT BD, RTANO, 17704 COMT, PIACE	LLULU	00020 000
A70R106	317-0100-00			RES, FXD, CMPSN:10 OHM, 5%, 0.125W	01121	BB1005
A70R109	307-0706-00			RES NTWK, FXD, FI:4, 10K OHM, 2%, 0.2W EA	01121	208B103
A70R221	321-0292-07			RES, FXD, FILM: 10.7K OHM, 0.1%, 0.125W, TC=T9	24546	NE55E1072B
A70R222	321-0463-00			RES, FXD, FILM: 649K OHM, 1%, 0.125W	19701	5033ED649K0F
A70R309	317-0151-00			RES.FXD.CMPSN:150 OHM.5%.0.125W	01121	BB1515
A70R313	317-0510-00			RES, FXD, CMPSN:51 OHM, 5%, 0.125W	01121	BB5105
A70U11E	150 0005 01			MICROCKE DOTI . O DIT DDI LOAD CHIET DOTD	27014	74C165NA+
A70U115	156-0625-01			MICROCKT, DGTL:8 BIT PRL LOAD SHIFT RGTR	27014	
A70W120	195-1715-00			LEAD, ELECTRICAL:26 AWG, 2.5 L, 9-2	80009	195–1715–00
				CHASSIS PARTS		
DL319 J100	175-1580-01 131-1811-00			CABLE, SP, ELEC: 26 AWG SOLID TWISTED PAIR TERM SET, PIN: 10, 0.025 SQ ON 0.15 CTR	80009 22526	175-1580-01 65595-110
J135	196-0797-00			FLEX CIRCUIT:36 CONDUCTOR, COPPER	80009	196-0797-00
J200	131-1811-00			TERM SET, PIN: 10, 0.025 SQ ON 0.15 CTR	22526	65595-110
J300	131-1811-00			TERM SET, PIN:10, 0.025 SQ ON 0.15 CTR	22526	65595-110
J301	131-1812-00			TERM SET, PIN:10,0.025 SQ ON 0.15 CTR	22526	65603-110
R104	317-0111-00			RES,FXD,CMPSN:110 OHM,5%,0.125W	01121	BB1115
R105	317-0111-00			RES, FXD, CMPSN:110 OHM, 5%, 0.125W	01121	BB1115
R107	317-0111-00			RES.FXD.CMPSN:110 OHM.5%.0.125W	01121	BB1115
R108	317-0111-00			RES. FXD. CMPSN:110 OHM, 5%, 0.125W	01121	BB1115
R204	317-0111-00			RES, FXD, CMPSN:110 OHM, 5%, 0.125W	01121	BB1115
R205	317-0111-00			RES, FXD, CMPSN:110 OHM, 5%, 0.125W	01121	BB1115
R208	317-0111-00			RES.FXD.CMPSN:110 OHM.5%.0.125W	01121	BB1115
R304	317-0111-00			RES, FXD, CMPSN:110 OHM, 5%, 0.125W	01121	BB1115
R306	317-0111-00			RES, FXD, CMPSN:110 OHM, 5%, 0.125W	01121	BB1115
R308	317-0111-00			RES, FXD, CMPSN:110 OHM, 5%, 0.125W	01121	BB1115
S100	260-0735-01			SWITCH, PUSH: T, NO CONTACT, BLACK BTN	81073	39-3
U302				MICROCIRCUIT, DI:LOGIC ACQ CIRCUIT (NOT REPLACEABLE, ORDER 672-1119-01)	210/0	00 0

			3
			0
×			

## REPLACEABLE MECHANICAL PARTS

#### PARTS ORDERING INFORMATION

Replacement parts are available from or through your local Tektronix, Inc. Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest circuit improvements developed in our engineering department. It is therefore important, when ordering parts, to include the following information in your order: Part number, instrument type or number, serial number, and modification number if applicable.

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc. Field Office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

#### SPECIAL NOTES AND SYMBOLS

X000 Part first added at this serial number 00X Part removed after this serial number

#### FIGURE AND INDEX NUMBERS

Items in this section are referenced by figure and index numbers to the illustrations.

#### INDENTATION SYSTEM

This mechanical parts list is indented to indicate item relationships. Following is an example of the indentation system used in the description column.

1 2 3 4 5

Name & Description

Assembly and/or Component
Attaching parts for Assembly and/or Component

Detail Part of Assembly and/or Component Attaching parts for Detail Part

Parts of Detail Part Attaching parts for Parts of Detail Part

Attaching Parts always appear in the same indentation as the item it mounts, while the detail parts are indented to the right. Indented items are part of, and included with, the next higher indentation. The separation symbol - - - \* - - - indicates the end of attaching parts.

Attaching parts must be purchased separately, unless otherwise specified.

#### ITEM NAME

In the Parts List, an Item Name is separated from the description by a colon (:). Because of space limitations, an Item Name may sometimes appear as incomplete. For further Item Name identification, the U.S. Federal Cataloging Handbook H6-1 can be utilized where possible.

#### **ABBREVIATIONS**

INCH	FLOTON	FLECTRON	***		200	
						SINGLE END
					SECT	SECTION
					SEMICONE	SEMICONDUCTOR
			INTL	INTERNAL	SHLD	SHIELD
		ELECTRICAL PARTS LIST	LPHLDR	LAMPHOLDER	SHLDR	SHOULDERED
ALUMINUM	EQPT	EQUIPMENT	MACH	MACHINE		SOCKET
ASSEMBLED	EXT	EXTERNAL	MECH	MECHANICAL		SLIDE
ASSEMBLY	FIL	FILLISTER HEAD		MOUNTING		SELF-LOCKING
ATTENUATOR	FLEX	FLEXIBLE		NIPPLE		SLEEVING
AMERICAN WIRE GAGE				711 1 ==		SPRING
BOARD						SQUARE
BRACKET						STAINLESS STEEL
BRASS						STEEL
BRONZE			PH BRZ	PHOSPHOR BRONZE		SWITCH
BUSHING	FXD	FIXED	PL	PLAIN or PLATE	т.	TUBE
CABINET	GSKT	GASKET	PLSTC	PLASTIC	TERM	TERMINAL
CAPACITOR		HANDLE	PN	PART NUMBER		THREAD
CERAMIC			PNH			THICK
CHASSIS			PWR			TENSION
CIRCUIT					11.0.0.000	TAPPING
COMPOSITION						TRUSS HEAD
						VOLTAGE
						VARIABLE
		(2) (3) (4) (3) (3) (3) (4) (4) (3) (4) (4) (4) (4) (4) (4) (4) (4) (4) (4				WITH
						WASHER
						TRANSFORMER
DRAWEN	IMPLR	IMPELLER	SCH	SCHEW	XSTR	TRANSISTOR
	ASSEMBLY ATTENUATOR AMERICAN WIRE GAGE BOARD BRACKET BRASS BRONZE BUSHING CABINET CAPACITOR CERAMIC CHASSIS	NUMBER SIZE ACTUATOR ADAPTER ALIGNMENT ALIGNMENT ASSEMBLED ASSEMBLY ATTENUATOR AMERICAN WIRE GAGE BOARD BRACKET BRACKET BRANZE BUSHING CABINET CAPACITOR CHASSIS COMPOSITION CONNECTOR COVER COUPLING CATHODE RAY TUBE D DEGREE  LLC LLC ELC ELC ELC ELC ELC ELC ELC	NUMBER SIZE ACTUATOR ADAPTER ALIGNMENT ALIGNMENT ALIGNMENT ASSEMBLED ASSEMBLY ATTENUATOR BOARD B	NUMBER SIZE ACTUATOR ACTUATOR ADAPTER ALIGNMENT ALIGNMENT ALIGNMENT BPL ASSEMBLED ASSEMBLY ATTENUATOR ATTENUATOR BRACKET BRACKET BRACKET BUSHING BUSHING BUSHING BUSHING CERAMIC CHASSIS CHARLE CHAR	NUMBER SIZE ACTUATOR ACTUATOR ADAPTER ALIGNMENT ALIGNMENT ALIGNMENT ASSEMBLED ASSEMBLY ATTENUATOR BOARD BOAR	NUMBER SIZE  LEC  LECTRICAL  INCAND  INCANDESCENT  SECT  ACTUATOR  ADAPTER  ADAPTER  ELEM  ELEMENT  ALIGNMENT  EPL  ELECTRICAL PARTS LIST  ALUMINUM  EQPT  EQUIPMENT  ASSEMBLED  EXT  EXTERNAL  ASSEMBLY  ATTENUATOR  FLEX  FLEXIBLE  BOARD  BOARD  FLTR  FILTER  BRACKET  FR  FR  FR  FR  FR  FR  FR  FR  FR  F

#### CROSS INDEX - MFR. CODE NUMBER TO MANUFACTURER

Mfr. Code	Manufacturer	Address	City, State, Zip Code	
06383	PANDUIT CORP	17301 RIDGELAND	TINLEY PARK IL 07094-2917	
73743	FISCHER SPECIAL MFG CO	111 INDUSTRIAL RD	COLD SPRING KY 41076-9749	
77900	SHAKEPROOF	SAINT CHARLES RD	ELGIN IL 60120	
	DIV OF ILLINOIS TOOL WORKS			
80009	TEKTRONIX INC	14150 SW KARL BRAUM DR	BEAVERTON OR 97077	
		PO BOX 500 MS 53-111		
TK1148	ACACIA SALES INC (DIST)	7763 SW CIRRUS DR	BEAVERTON OR 97005-6452	
	TO SOME THE STATE OF SECTIONS OF SECTION SECTIONS OF SECTION SECTIONS OF SECTION SECTI	BLDG 26		
TK1319	MORELLIS Q & D PLASTICS	1812 16-TH AVE	FOREST GROVE OR 97116	
TK1374	TRI-TEC ENGINEERING CORP	13130 S NORMANDIE	GARDENA CA 90249-2128	
TK1415	CABOT CORP	7911 ZIONSVILLE RD	INDIANAPOLIS IN 46268	
	E.A.R. DIV			

Fig. &							
Index	Tektronix	Serial/Asse	mbly No.			Mfr.	
No.	Part No.	Effective	Dscont	Qty	12345 Name & Description	Code	Mfr. Part No.
1-				1	P6460:PROBE.DATA ACQ		
-1	334-4855-00			ī	.MARKER, IDENT:MKD DIAGNOSTIC	80009	334-4855-00
-2	380-0711-00			ī	. HOUSING, PROBE: UPPER, PC	80009	
-3	348-0390-00			ī	.CUSHION, PROBE:1.5 X 2.0 X 0.125		ORDER BY DESCR
-4	380-0710-00			ī	.HOUSING.PROBE:LOWER.PC		380-0710-00
				-	.(ATTACHING PARTS)	00000	000 0/10 00
-5	211-0086-00			4	.SCREW, MACHINE: 4-40 X 0.75, FLH, 100 DEG, STL	80009	211-0086-00
-6	210-0406-00			4	.NUT, PLAIN, HEX: 4-40 X 0.188, BRS CD PL	73743	12161-50
					.(END ATTACHING PARTS)		
-7	200-2731-00			2	.COVER, HOLE: POLYCARBONATE, GRAY	80009	200-2731-00
-8	175-6807-00		B036539	1	.CA ASSY, PROBE: 2 METERS	TK1374	ORDER BY DESCR
	175-9843-00	B036540		1	.CA ASSY,SP,ELEC:22,28 AWG,76.0 L	TK1374	ORDER BY DESCR
	672-1119-01			1	.CIRCUIT BD ASSY:MAIN	80009	672-1119-01
-9				1	SWITCH, PUSH: (SEE S100 REPL)		
					(ATTACHING PARTS)		
-10	358-0660-00			1	BUSHING,SW MTG:AL	80009	358-0660-00
-11	210-0008-00			1	WASHER,LOCK:#8 INTL,0.02 THK,STL	77900	1208-00-00-0541C
					(END ATTACHING PARTS)		
-12	358-0674-00			1	STRAIN RLF,CA:LOWER		358-0674-00
-13	358-0675-00			1	STRAIN RLF,CA:UPPER	80009	358-0675-00
-14	361-0758-01			1	SPACER, PROBE: ACETAL SLATE GRAY	80009	361-0758-01
-15				1	TERM SET, PIN: (SEE J100, J200, J300 REPL)		
-16	348-0782-00			2	CUSHION, HYBRID: SILCON SPONGE	80009	348-0782-00
-17				1	TERM SET, PIN: (SEE J301 REPL)		
-18	346-0120-00			2	STRAP, TIEDOWN, E:5.5 L MIN, PLASTIC		SST1.5M
-19	343-1095-00			1	CLAMP, HYB CKT:0.295 ID, ALUMINUM	80009	343-1095-00
-20	426-1985-00			1	FRAME, WINDOW:	80009	426-1985-00
-21	386-5017-00			1	PLATE, PRESSURE:		386-5017-00
-22	343-1094-00			1	RETAINER,CONN:SILICONE FOAM		ORDER BY DESCR
-23	196-0797-00			1	FLEX CIRCUIT:36 CONDUCTOR, COPPER	80009	196-0797-00
-24				1	CKT BOARD ASSY:MAIN(SEE A70 REPL)		
-25				1	CONN,RCPT,ELEC:(SEE A70J126 REPL)		

2				
*				

Fig. &	<b>*</b> 1									
Index	Tektronix	Serial/Asse		04	10045	N 0 D	Mfr.	MC- D+ N-		
No.	Part No.	Effective	DSCONT	Qty	12345	Name & Description	Code	Mfr. Part No.		
2-										
					STANDAR	RD ACCESSORIES				
	070-4345-00			1	SHEET,T	ECHNICAL: INSTR,010-6460-00	80009	070-4345-00		
	020-0720-00	B010100	B035539	1	ACCESSO	ORY KIT: PKG OF 12,206-0222-00	80009	020-0720-00		
	020-1386-00	B035540		1	ACCESSO	ORY KIT: PACKAGE OF 12(013-0217-00)	80009	020-1386-00		
	012-0747-00			1	LEAD SE	T,ELEC:10 WIDE,25 CML	80009	012-0747-00		
	012-0989-00			2		T,ELEC:GROUND OR VL SENSE LEAD 4.0 L W/PAMONA CLIP	80009	012-0989-00		
	334-4854-00			1	MARKER,	IDENT: MKD DATA ACQUISITION PROBE	80009	334-4854-00		
	334-4856-00			1		IDENT:MKD P6460 ACQUISITION PROBE	80009	334-4856-00		
	344-0046-00			2	CLIP, EL	ECTRICAL:ALLIGATOR, 1.56 L, STL BRT	80009	344-0046-00		
					OPTIONA	AL ACCESSORIES				
	003-0709-00			1	EXTRACT	OR,1C:16 PIN TEST CLIP	80009	003-0709-00		
	012-0556-00			1		T, ELEC: DIAGNOSTIC		ASI 61500 REV A		
	012-0800-00			1		T,ELEC:10.WIDE,9.843 L		012-0800-00		
	012-0987-00			1	LEAD SE	T,ELEC:10 WIDE,5.0 L	80009	012-0987-00		
	012-0989-01			1	LEAD SE	T,ELEC:GROUND OR VL SENSE LEAD 4.0 L	80009	012-0989-01		
					,BLACK	W/PAMONA CLIP				
	012-1000-00			1		T,ELEC:12 WIDE,10.0 L	80009	012-1000-00		
	015-0330-00			1		EST CLIP:16 DIP	80009	015-0330-00		
	015-0339-00			1		EST CLIP:40 DIP	80009	015-0339-00		
	015-0339-02			1		EST CLIP:40 DIP	80009	015-0339-02		
	103-0209-00			1		,CONN:GPIB TO PROBE	80009	103-0209-00		
	380-0560-05			1	HOUSING	,TERM:MALE ADAPTER	80009	380-0560-05		

			i.
		Ţ	

## **DIAGRAMS AND CIRCUIT BOARD ILLUSTRATIONS**

#### **Symbols**

Graphic symbols and class designation letters are based on ANSI Standard Y32.2-1975.

Logic symbology is based on ANSI Y32.14-1973 in terms of positive logic. Logic symbols depict the logic function performed and may differ from the manufacturer's data.

The overline on a signal name indicates that the signal performs its intended function when it is in the low state.

Abbreviations are based on ANSI Y1.1-1972.

Other ANSI standards that are used in the preparation of diagrams by Tektronix, Inc. are:

Y14.15, 1966 Drafting Practices.

Y14.2, 1973 Line Conventions and Lettering.

Y10.5, 1968 Letter Symbols for Quantities Used in

Electrical Science and Electrical Engineering.

American National Standard Institute 1430 Broadway . New York, New York 10018

#### **Component Values**

Electrical components shown on the diagrams are in the following units unless noted otherwise:

Capacitors = Values one or greater are in picofarads (pF). Values less than one are in microfarads  $(\mu F)$ .


Resistors = Ohms  $(\Omega)$ .


#### - The information and special symbols below may appear in this manual.

#### **Assembly Numbers and Grid Coordinates**

Each assembly in the instrument is assigned an assembly number (e.g., A20). The assembly number appears on the circuit board outline on the diagram, in the title for the circuit board component location illustration, and in the lookup table for the schematic diagram and

corresponding component locator illustration. The Replaceable Electrical Parts list is arranged by assemblies in numerical sequence; the components are listed by component number \*(see following illustration for constructing a component number).






P6460 Board

Static Sensitive Devices
See Maintenance Section

#### COMPONENT NUMBER EXAMPLE



Chassis-mounted components have no Assembly Number prefix—see end of Replaceable Electrical Parts List.