## T Unit Calibration Outline

Horiz. Pos. at 12:00 Adjust to start trace
at left age of graticule
200mv external
.1 & ims
.1 & 1ms
20mc 2cm of signal

For excessive jitter -- Look for dirty capacitor grounding bands
Try disconnecting electrolytic cap leads

