


P.M.P.C.  
067-0099-00  
POCKET PULSER POWER SUPPLY

This supply replaces the battery in your 017-0086-00 pulser, allowing you to "plug your pulser" in the wall.

To adapt your pulser, replace the battery containing end-bell with the modified end-bell supplied.

The Power Supply will not be harmed if allowed to operate without a load, or if the output is shorted.



12-10-63

12-12-64 FMS/bg  
1-4-67 PMPC/sw