


TO LOGIC ANALYZER



Static Sensitive Devices
See Maintenance Section

COMPONENT NUMBER EXAMPLE

Component Number	A23 A2 R1234
Assembly Number	
Subassembly Number (if used)	
Schematic Circuit Number	
Number	

Chassis-mounted components have no Assembly Number prefix—see end of Replaceable Electrical Parts List.

