

FACTORY CALIBRATION PROCEDURE

CONTENTS:

This is the guide for calibrating new instruments in Product Manufacturing. The procedure consists of 4 sections:

Equipment Required

Factory Test Limits - Factory Test Limits are limits an instrument must meet before leaving Manufacturing. These limits are often more stringent than advertised performance requirements. This is to insure that the instrument will meet advertised requirements after shipment, allows for individual differences in test equipment used, and (or) allows for changes in environmental conditions.

*This procedure is
company confidential*

581A

Short Form Procedure - The Short Form Procedure has the same sequence of steps and the same limits on checks or adjustments as the Main Procedure.

December 1968

For all serial numbers.



Main Procedure - The Main Procedure gives more detailed instructions for the calibration of the instrument. This procedure may require that some checks and adjustments be made so that performance is better than that required by the Factory Test Limits. This insures the Factory Test Limits will be met when side panels are added, permits some normal variation in test equipment and plug-in scopes, etc.

Abbreviations in this procedure will be found listed in TEKTRONIX STANDARD A-100. Definitions of terms used in this procedure may be found in TEKTRONIX STANDARD A-101.

In this procedure, all front panel control labels and Tektronix instrument names are in capital letters (VOLT/DIV, etc). Internal adjustment labels are capitalized only (Gain Adj, etc).

CHANGE INFORMATION:

This procedure has been prepared by Product Manufacturing Staff Engineering. For information on changes made to this procedure, to make suggestions for changing this procedure, or to order additional copies: please contact PMSE, 39-307.

©, 1968 TEKTRONIX, INC., PO Box 500
BEAVERTON, OREGON. All rights reserved.



PMSE

COMPANY CONFIDENTIAL

Page 1 of 31

EQUIPMENT REQUIRED:

The following equipment is necessary to complete this procedure:

a. TEKTRONIX Instruments

- 1 TYPE 535A OSCILLOSCOPE
- 1 TYPE B PLUG-IN UNIT (test scope) (modified PMIE Dwg #2145A)
- *1 TYPE 184 TIME-MARK GENERATOR
- *1 TYPE 191 CONSTANT AMPLITUDE SIGNAL GENERATOR
- 1 TYPE 76TU LINE VOLTAGE CONTROL UNIT
- 1 TYPE P6028 1X PROBE
- 1 TYPE P6006 10X PROBE

b. Test Fixtures and Accessories

- *1 Standard Amplitude Calibrator (SAC) (067-0502-00)
- 1 Bandwidth Plug-In (PMIE Dwg 1348B-1345B)
- *1 Calibration Fixture (067-0523-00) (TYPE 84) (modified PMIE Dwg #1897-C)
- 1 Variable Attenuator (PMIE Dwg #2090-B)
- 3 50 Ω BNC cables (012-0057-00)
- 2 50 Ω Termination, BNC (011-0049-00)
- 1 Clip Lead Adapter (013-0076-00)
- 1 BNC T connector (017-0069-00)
- 1 Micro shock hammer (PMIE Dwg #1283B)
- 1 DC Voltage Bridge (DCVB) (067-0543-99)
- 1 Low Frequency Sinewave Generator (LFSWG) (067-0542-99)
- 2 BNC to Banana plug patch cords (012-0091-00)

c. Other equipment

- 1 Multimeter 20,000 Ω /Volt

d. Equipment for Sample Checks

- 1 Constant Amplitude Signal Generator (CASG) (067-0532-00)
- 1 50 Ω Termination (GR to BNC) (017-0083-00)

* Equipment must be traceable to NBS for certification of measurement characteristics.

Substitute test equipment may be used. The Plant Staff Engineer must approve any substitutions. All equipment listed must perform within its manufacturer's specifications, unless otherwise stated.

FACTORY TEST LIMITS

Factory Test Limits are qualified by the conditions specified in the main body of the Factory Calibration Procedure. The numbers and letters to the left of the limits correspond to the procedure steps where the check or adjustment is made. Steps without Factory Test Limits (setups, presets, etc.) are not listed. Instruments may not meet Factory Test Limits if calibration or checkout methods and test equipment differ substantially from those in this procedure.

1. PRELIMINARY INSPECTION

- d. CRT faceplate tilt, $\pm 3/64$; Graticule align, $\pm 1\text{mm}$
- g. Fuse, 3ag, 7a mdx slo-blo

3. RESISTANCE

- b. Cal Test Pt: approx $20\text{k}\Omega$ to ground

4. LOW VOLTAGE POWER SUPPLIES

- a. Time-delay relay: 15 to 60 sec
- b. Low voltage power supply regulation and ripple:

<u>SUPPLY</u>	<u>TOLERANCE</u>	<u>RIPPLE</u>
-150V	$\pm 3\text{V}$	5mV
+100V	$\pm 2\text{V}$	15mV
+225V	$\pm 4.5\text{V}$	5mV
+350V	$\pm 7\text{V}$	30mV
+500V	$\pm 10\text{V}$	30mV

- d. Regulation of +12.6V supply, $\pm 1\%$, ripple 15mV, max

5. HIGH VOLTAGE AND CRT

- a. HV Supply: $-1350 \pm 2\%$
- b. HV regulation: no trace blooming or voltage change $> 20\text{V}$ from 105 to 125VAC.
- d. Trace alignment range: 6° min; alignment $\pm 1\text{mm}$, max

6. GEOMETRY

- b. Vertical geometry: 0.67mm max bowing
- c. Horiz geometry: 0.67mm max bowing

7. FOCUS

- a. Horizontal focus: no overlap of 1mm marks in the center 8.8cm
- b. Vertical focus: no overlap of 1mm spaced lines

8. BEAM INDICATORS AND SCALE ILLUMINATION

- b. Beam position indicators: the correct neon must be lit and the opposite neon off before the spot leaves the graticule.
- c. SCALE ILLUM: max cw, off ccw
- f. Alternate sweep: all sweep rates

9. VERTICAL AMPLIFIER LF

- d. Vertical amplifier balance: 0.5cm max from electrical center
- e. Microphonics: 0.25cm, max no ringing type
- f. Vert Gain Adj: range $+15\%$ to -5%
- g. Compression/expansion: 0.5mm, max
- h. DC shift: 1mm, max
- i. Vertical drift, 105 to 125VAC: 2mm max

10. CRT CATHODE INPUT
 - b. Intensity modulation: 20V
11. AMPLITUDE CALIBRATOR
 - *b. .1 VOLTS position: $\pm 2\%$
 - *c. 50V to .2V position
observed error: $\pm 2\%$
observed error plus 1000:1 divider
error: $\pm 2\%$
 - e. Calibrator frequency: 1 kHz $\pm 20\%$
 - f. Calibrator duty cycle: 45 to 55%
12. TIME BASE A TRIGGERING
 - b. Trig Level Centering: + & - triggering on 1mm
 - c. Trig Sens: + & - triggering on 1/2mm, no triggering on 1/4mm
 - d. Internal and external midrange triggering: 1 kHz; 2mm INT, 0.2V EXT
10MHz; 2mm INT, 0.3V EXT
3mm INT, 0.3V EXT
0.2V EXT HF SYNC
13. LINE TRIGGERING
 - b. Line triggering: correct slope
14. PRESET ADJUST
 - b. PRESET ADJUST: center of range, $\pm 25\%$
15. TRIGGERING LEVEL RANGE
 - b. TRIGGERING LEVEL range: 15V min
16. MAGNIFIER GAIN
 - *b. Mag Gain Adj: $\pm 3\%$
Magnified sweep linearity: $\pm 1\%$
- *17. SWEEP CALIBRATION $\pm 2\%$
18. TIME BASE A SWEEP LENGTH
10.2 to 10.8cm
19. NORMAL-MAGNIFIED REGISTRATION
 $\pm 2\text{mm}$ at graticule center
20. VARIABLE TIME/CM
 - a. VARIABLE TIME/CM ratio: 2.5:1 min
 - b. VARIABLE neon: lit except in CALIBRATED
21. TIMING
 - *a. Timing:
.1mSEC-.5 SEC: $\pm 2\%$, max
1 and 2 SEC: $\pm 2.5\%$, max
 - *c. Timing:
.05 μ SEC-50 μ SEC: $\pm 2\%$, max
Magnified sweep: $\pm 3\%$, max
Linearity: $\pm 1\%$, max.
22. LOCKOUT LEVEL
 - a. Set Lockout level: 9V to 11V
 - b. Check SINGLE SWEEP triggering: sweeps once on triggering signal.
23. + GATE INTERVAL & FRONT PANEL WAVEFORMS
 - b. + GATE Interval: Limits in table, Amplitude; 20V -in

TIME/CM	A
.05 to .5 μ SEC	3-9 μ S
1 to 50 μ SEC	15-40 μ S
.1 to .5mSEC	150-400 μ S
1 to 5mSEC	1.5-4ms
10 to 50mSEC	15 to 40ms
.1 to 2 SEC	150 to 400ms
 - c. SAWTOOTH OUT: $\geq 130\text{V}$
 - d. + GATE OUT: $\geq 20\text{V}$

24. EXTERNAL HORIZONTAL

- a. Ext Horiz DC Bal: $\pm 1\text{cm}$ max shift
- b. Grid current: $\pm 0.5\text{cm}$ max shift
- c. X10 to X1 match $\pm 5\%$
- d. External deflection factor:
 .2 VOLTS/CM max
- e. EXT X10 attenuation: divides X1 gain
 by 10 $\pm 2\%$
- f. VARIABLE 10:1 ratio: 10:1 min
- *g. Bandwidth: 350 kHz or more at -3dB

SAMPLE CHECKS

- I. HF SYNC at 250 MHz
 INT 4mm: EXT 0.2V P-P

THE END

25. VERTICAL HF COMPENSATIONS

- *c. Vertical gain $\pm 2\%$ max
- h. Vertical aberrations: Flatness $\leq 2\%$ P-P
 from 1mSEC to .05 μ SEC

* Indicates measurement characteristic;
test equipment used must be traceable
to NBS for instrument certification.

26. VERTICAL DELAY

Vertical delay: 40ns, min

27. VERTICAL BANDWIDTH

- b. Vertical bandwidth: 95 MHz or more
 at -3dB

28. HIGH FREQUENCY TRIGGERING

- a. External HF triggering:
 0.4V at 50 MHz, 1.2V at 100 MHz,
 1.5V at 150 MHz, HF SYNC 0.2V at 150 MHz
- b. Internal HF triggering:
 INT 1cm at 50 MHz, 2cm at 100 MHz,
 2.5cm at 150 MHz, HF SYNC 3mm at 150 MHz

29. LOW FREQUENCY TRIGGERING

TIME BASE LF triggering:
INT 2mm 15 Hz & 15 kHz
EXT 0.3V 15 Hz & 15 kHz

SHORT FORM PROCEDURE

This instrument must meet Factory Test Limits before it leaves Manufacturing; therefore, it must be possible to inspect to these limits. Because of normal variations in test equipment and plug-in scopes, addition of side panels, etc, this procedure may require that some checks and adjustments be made so that performance is better than that required by Factory Test Limits.

1. PRELIMINARY INSPECTION

- a. Check for current modifications
- b. Check tubes
- c. Align CRT
- d. Check CRT pins
- e. Check CRT
- f. Check fuse
- g. Check anode button

2. PRESET CONTROLS

3. RESISTANCE

- b. Measure resistance

4. LOW VOLTAGE POWER SUPPLIES

- a. Check time-delay relay: 15 to 60 sec
- b. Adjust -150V and check regulated voltages
- c. Check elevated heaters
- d. Adjust and check regulation of +12.6V supply: $\pm 1\%$, ripple 15mV max

5. HIGH VOLTAGE AND CRT

- a. Adjust HV Adj R840: -1350
- b. Check HV regulation
- c. Adjust Shield Volts Adj R860
- d. Check trace align range: 6° min
Align trace: $\pm 1\text{mm}$

6. GEOMETRY

- b. Adjust geometry R861: 0.67mm max bowing
- c. Check horiz geometry: 0.67 max bowing

7. FOCUS

- a. Check horiz focus
- b. Check vert focus

8. BEAM INDICATORS AND SCALE ILLUMINATION

- b. Check beam position indicators
- c. Check SCALE ILLUM: max cw, off ccw
- d. Check 5X MAGNIFIER Indicator
- e. Check VARIABLE Indicator
- f. Check alternate sweep: all sweep rates

9. VERTICAL AMPLIFIER LF

- a. Find CRT electrical center
- b. Adjust R1294
- c. Check for loose tube socket connections
- d. Check vertical amplifier balance 0.5cm max, from electrical center
- e. Check for microphonics 0.25cm max, no ringing
- f. Check range: $\pm 15\%$, -5%
Set gain
- g. Check compression/expansion: 0.5mm max
- h. Check DC shift 1mm, max
- i. Check vertical drift, 105 to 125 VAC 2mm, max

10. CRT CATHODE INPUT

- a. Remove CRT GND strap
- b. Check intensity modulation 20V

11. AMPLITUDE CALIBRATOR

- b. Check .1 volts position: $\pm 2\%$
- c. Check 50V to .2V positions:
observed error: $\pm 2\%$
observed error + 1000:1 divider
error: $\pm 2\%$
- d. Check 50mV to .2mV operation
- e. Check calibration frequency: 1 kHz
 $\pm 20\%$
- f. Check calibrator duty cycle: 45 to 55%

12. TIME BASE TRIGGERING

- a. Set TRIGGERING LEVEL mechanical
zero: 0V
- b. Adjust Trig Level Centering R25: + & -
triggering on 1mm
- c. Adjust Trig Sens R47: + & - triggering
on $\frac{1}{2}$ mm, no triggering on $\frac{1}{4}$ mm
- d. Check internal and external midrange
triggering:
1 kHz, 2mm INT, 0.2V EXT
10 MHz, 2mm INT, 0.3V EXT
3mm INT HF SYNC, 0.2V EXT HF SYNC

13. LINE TRIGGERING

- b. Check triggering: correct slope

14. PRESET ADJUST

- b. Adjust PRESET ADJUST: center of range

15. TRIGGERING LEVEL RANGE

- b. Check TRIGGERING LEVEL range: 15V min

16. MAGNIFIER GAIN

- b. Adjust Mag Gain Adj R372

17. SWEEP CALIBRATION

Adjust Swp Cal R348

18. SWEEP LENGTH

Adjust Swp Length R176: 10.5cm

19. NORMAL-MAGNIFIED REGISTRATION

Adjust Norm Mag Regis, R358:
 ± 2 mm

20. VARIABLE TIME/CM

- a. Check VARIABLE TIME/CM ratio:
2.5:1 min
- b. Check neon: lit except in
CALIBRATED

21. TIMING

- a. Check timing
.1mSEC-.5 SEC: $\pm 2\%$ max
1 and 2 SEC: $\pm 2.5\%$ max
- b. Adjust C330
- c. Adjust and check timing
.05 μ SEC-50 μ SEC: $\pm 2\%$ max
Magnified sweep: $\pm 3\%$ max
Linearity: $\pm 1\%$ max

22. LOCKOUT LEVEL

- a. Set Lockout Level: 9V to 11V
- b. Check SINGLE SWEEP triggering:
sweeps once on triggering signal

23. + GATE INTERVAL

- b. Check + GATE Interval: Amplitude
20V min
- c. Check ~~SAWTOOTH~~ OUT: ≥ 130 V
- d. Check + GATE OUT: ≥ 20 V

24. EXTERNAL HORIZONTAL

- a. Adjust EXT Horiz DC Bal, R317:
 ± 1 cm max shift
- b. Check for grid current: ± 0.5 cm
shift
- c. Adjust C3016: X10 to X1 match $\pm 5\%$
- d. Check external horizontal deflection
factor: 0.2 VOLTS/CM max

24. (CONT)

- e. Check EXT X10 attention:
divides X1 gain by 10 $\pm 2\%$
- f. Check VARIABLE 10:1 ratio:
10:1 min
- g. Check bandwidth: 350kHz or
more at -3dB

25. VERTICAL HF COMPENSATIONS

- b. Preset amplifier
- c. Recheck vertical gain $\pm 2\%$ max
- d. Adjust C1209, C1006
- e. Adjust C1214 thru C1254
- f. Adjust C1260, C1261
- g. Adjust R1293, C1276
- h. Check Vertical aberrations:
Flatness $\leq 2\%$ P-P from 1mSec to
.05 μ Sec
- i. Select R1204, C1204, R1205 &
C1205
- j. Check with side panel

26. VERTICAL DELAY 40nsec min

27. VERTICAL BANDWIDTH

- b. Check Vertical Bandwidth:
95MHz or more at -3dB

28. HIGH FREQUENCY TRIGGERING

- a. Check external HF triggering:
EXT 0.4V at 50MHz; 1.2V
100MHz; 1.5V at 150MHz;
HF SYNC 0.2V at 150MHz
- b. Check Internal HF triggering:
INT 1cm at 50MHz; 2cm at
100MHz; 2.5cm at 150MHz; HF
SYNC 3mm at 150MHz

29. LOW FREQUENCY TRIGGERING

Check LF triggering
INT 2mm 15Hz and 15kHz,
EXT 0.3V 15Hz and 15kHz

SAMPLE CHECKS

I HF SYNC at 250MHz

Check HF SYNC INT 4mm; EXT 0.2V P-P,
at 250MHz

THE END

1. PRELIMINARY INSPECTION*a. Check modification*

Check that instruments have all current modifications.

b. Check tubes

Check all tubes for proper type and installation:

Horizontal Amplifier	No G.E.
Vertical Output	All tubes are the same brand and manufactured in the same country
Distributed Amplifier	Same
Delay line drivers	Same

c. Align CRT: CRT faceplate tilt, $\pm 3/64$; Graticule align $\pm 1\text{mm}$

Loosen allen screws on CRT clamp and position the CRT so that the faceplate is equal distance from light deflector on both sides and top of CRT. Tighten the allen screws. Loosen CRT clamp and position CRT so that the faceplate is flush with the light deflector. Place scribed graticule over the CRT and align internal graticule with scribed graticule. Tighten the CRT clamp and remove the scribed graticule.

d. Check CRT pins

Check that the CRT pins cannot be pulled off of the neck pins using a pair of 6" tweezers.

e. Check CRT

Check that the CRT serial number and code date match that on the records. Check CRT for structural defects.

e. Do not reject a CRT without consulting a CRT checker or referring to the cathode ray tube checkout procedure.

f. Check Fuse

Check that the fuse is a 3ag, 7a mdx slo-blo.

g. Check anode button

Check that the anode button is properly seated.

2. PRESET CONTROLS

POWER ON	OFF
FOCUS	CCW
INTENSITY	CCW
ASTIGMATISM	CCW
SCALE ILLUM	CW
HORIZONTAL DISPLAY	INTERNAL SWEEP
5X MAGNIFIER	OFF
STABILITY	CCW
TRIGGER SLOPE	+
TRIGGERING SOURCE	INT AC
TIME/CM	1mSEC
VARIABLE TIME/CM	CALIBRATED
PRESET ADJ	CCW
All internal adjustments midr	

Leave controls and adjustments for any step as they were in the preceding step unless otherwise noted.

3. RESISTANCE*a. Setup*

Install the TYPE 84 in the TYPE 581A and preset it as follows:

LOAD	NORM
DISPLAY SELECTOR	EXT INPUT
VERTICAL POSITION	midr

b. Measure resistance

Connect multimeter to proper slots on ceramic strips next to power transformer. Measure the resistance to ground as follows:

<u>Terminal or slot</u>	<u>Approx Resistance</u>
Transformer term 1	infinite
Transformer term 4	infinite
+12.6	.7 Ω
-150V	3k
+100V	1.5k
+225V	2.2k
+350V	20k
+500V	30k
+325V unreg	3.5k

Check Cal Test Pt. for approx 20k Ω to ground.

4. LOW VOLTAGE POWER SUPPLIES

- a. *Check time-delay relay: 15 to 60 sec*

Apply power to the TYPE 581A via a TYPE 76TU and check time-delay relay as follows: Set the line voltage to 117 VAC with the TYPE 76TU. Turn the POWER ON switch ON. Check that no regulated power supply voltages are present before the time delay relay closes. Check for a delay of 15 to 60 seconds before audible click is heard.

- b. *Adjust -150V and check regulated voltages*

Adjust -150V Adj for -150V. Switch the TYPE 84 LOAD switch to HIGH LOAD. Measure the regulated voltages (on power supply chassis). Check regulation at 105 VAC line voltage. Switch TYPE 84 to LOW LOAD and check regulation and ripple at 125 VAC.

<u>Supply</u>	<u>Tolerance</u>	<u>Ripple</u>
-150V	±3V	5mV
+100V	±2V	15mV
+225V	±4.5V	5mV
+350V	±7V	30mV
+500V	±10V	30mV

Return line voltage to 117 VAC.

- c. *Check elevated heaters*

Check elevated heater supplies for the proper voltage above GND:

<u>Transformer terminal</u>	<u>Approx DC Voltage to GND</u>
22 and 23	+50
27 and 28	+225
24 and 25	-1200 to -1500
9 and 16	+350

- d. *Adjust and check regulation of +12.5V supply ±1%, ripple; 15mV max*

Connect DCVB to the front end of C786 and adjust R785 for +12.6V. Check regulation between 105 VAC, HIGH LOAD and 125 VAC LOW LOAD. Connect X1 probe from test scope and check +12.6V ripple over the same AC voltage and Load range. Return line to 117V.

- b. Use the test scope to measure ripple and multimeter to measure voltage amplitude. The +100V max ripple limit includes HV hash.

The -150V supply may be adjusted anywhere within its ±3V limit to bring other supplies in tolerance.

5. HIGH VOLTAGE AND CRT

- a. *Adjust HV Adj R840: -1350*

Connect DCVB to HV Test Pt. Set High Voltage Adj R840 for -1350.

- b. *Check regulation: No trace blooming or voltage change >20V from 105 to 125 VAC*

Set FOCUS and ASTIGMATISM controls ccw, STABILITY and INTENSITY cw. Check for trace blooming and voltage change while varying line voltage from 105 to 125 VAC: No blooming and no voltage change greater than 20V (-1330 to -1370).

Return line voltage to 117 VAC, and TYPE 84 LOAD switch to NORM. Set INTENSITY to minimum usable level and adjust FOCUS and ASTIGMATISM controls for a focused trace.

- c. *Adjust Vert Shield Volts Adj R860:*

Connect the DC voltmeter between one of the rear CRT neck pins and the center arm of R860. Set the trace to graticule center. (Adjust trace rotation if necessary.) Set the Vert Shield Volts Adj, R860 for 0V.

- d. *Check trace alignment range: 6° min, alignment 1mm, max*

Set TRACE ROTATION at each extreme and check for 6 degrees or more total tilt. Cw pot rotation must cause cw trace rotation. Adjust trace parallel with horizontal graticule lines.

- d. TRACE ROTATION is adjusted through center of ASTIGMATISM knob. 6 degrees = 1cm difference in vertical height in 10cm of trace length. (See drawing)

6. GEOMETRY

- a. *Setup*

Apply 1mS and .1mS markers to the TYPE 84 EXT INPUT from TYPE 184. Set TIME/CM to 1mSEC. Adjust the VARIABLE TIME/CM control to get exactly 15 1mS markers in 10cm. The distance between .1mS markers is now 0.67mm.

6. (cont'd)

- b. *Adjust geometry R861: 0.67mm
max bowing*

Adjust for minimum bowing of the vertical lines. Check over the entire graticule for 0.67mm or less bowing in 4cm.

- c. *Check horizontal geometry: 0.67mm
max bowing*

Remove TYPE 184 markers off and turn TIME BASE A STABILITY cw. Use the TYPE 84 VERTICAL POSITION to check for bowing of the trace within the graticule area.

- 6 b. It may be necessary to use external triggers to obtain a stable display.

7. FOCUS

- a. *Check horizontal focus: no overlap
of 1mm marks in the center 8.8cm*

Turn TIME/CM to 1mSEC and apply .1mS markers from the TYPE 184.

Adjust the VARIABLE TIME/CM for 10 markers/cm. Adjust FOCUS and ASTIGMATISM so that all .1mS markers over the center 8.8cm of the graticule are clearly defined with no overlap.

Remove the TYPE 184 signal.

- b. *Check vertical focus: no overlap
of 1mm spaced lines*

Connect the SAC OUTPUT cable to the TYPE 84 EXT INPUT. Set the SAC for a display amplitude of 1mm or less at graticule center.

Use the TYPE 84 VERTICAL POSITION to check for no overlap of the traces at top, center, and bottom of the graticule. It may be necessary to set the TYPE 581A Vert Gain Adj for 1mm display amplitude. Remove signal and return VARIABLE TIME/CM to CALIBRATED.

7. R860 may be adjusted for optimum focus.

8. BEAM INDICATORS AND SCALE ILLUMINATION

- a. *Setup*

HORIZ DISPLAY
INTENSITY

EXT
to obtain spot

- 8 a. Use care to avoid burning CRT phosphor by keeping intensity at minimum usable level.

8. (cont'd)

b. Check beam position indicators

The spot must move off screen in the direction indicated. The proper beam position indicator must come on and the opposite neon must go off before the spot leaves the graticule.

<u>Position Control</u>	<u>Turn</u>	<u>Spot must move</u>	<u>Beam position indicator</u>
CALIBRATION FIXTURE VERTICAL POSITION	cw	up	↑
CALIBRATION FIXTURE VERTICAL POSITION	ccw	down	↓
TYPE 581A HORIZONTAL POSITION	cw	right	→
TYPE 581A HORIZONTAL POSITION	ccw	left	←

Turn 5X MAGNIFIER OFF.

c. Check SCALE ILLUM: max cw, off ccw

Turn SCALE ILLUM cw, max brilliance. Turn SCALE ILLUM ccw. No illumination.

d. Check 5X MAGNIFIER indicator

Neon must be off when the 5X MAGNIFIER knob is in the ccw (OFF) position and on when the 5X MAGNIFIER knob is in the cw (ON) position.

e. Check VARIABLE indicator

Neon must be off when the VARIABLE control is in the cw (CALIBRATED) position and on in all other positions of the VARIABLE control.

f. Check alternate sweep: all sweep rates

Switch TYPE 84 to ALTERNATE. Check all sweep rates.

Set TIME/CM switch to 1mSEC.

9. VERTICAL AMPLIFIER LF*a. Find CRT electrical center*

Set the STABILITY cw (free run) and refocus. Short front CRT vertical deflection plates together and note trace vertical position (CRT electrical center). Remove short.

9. (cont'd)

b. Adjust R1294

Connect a jumper between pin 2 of V1274 and pin 2 of V1284. Position the trace to electrical center with R1294. Remove the jumper.

c. Check for loose tube socket connections

Move the vertical amplifier tubes in their sockets while observing the trace. Check for no erratic shift.

*d. Check vertical amplifier balance
0.5cm max, from electrical center*

Short V1214 pin 2 to pin 7. The trace must not shift more than 0.5cm from previous stage or CRT electrical center.

Press the TYPE 84 SCOPE AMP BALANCE CHECK button. The trace must not shift more than 0.5cm from previous stage or electrical center.

*e. Check for microphonics 0.25cm max
no ringing type*

Set the TIME/CM switch to 10mSEC. Use the micro shock hammer on top of the TYPE 581A and check for 0.25cm or less of microphonics, with no ringing.

*f. Check range: +15% -5%, Set gain:
2cm \pm 2%*

Set TYPE 84 DISPLAY SELECTOR to PULSER. Connect PULSER AMPLITUDE OUT to UNKNOWN INPUT of the SAC. Set SAC AMPLITUDE to 50 volts, +DC, MIXED and connect SAC OUTPUT to the test scope. Set TYPE 84 PULSER AMPLITUDE for exactly 50 volts. Turn the Vert Gain Adj R1015 from full cw to full ccw: range must be 1.9 to 2.3cm. Adjust R1015 for exactly 2.0cm deflection.

9. (CONT)

- g. Check compression/expansion:
0.5mm max*

Position top of display to top graticule line and note compression or expansion: 0.5mm, max. Position bottom graticule line and again note compression or expansion: 0.5mm, max.

- h. Check DC shift: 1mm, max*

Set DISPLAY SELECTOR to EXT INPUT. Position the trace just off-screen in either vertical direction. Push the CALIBRATION FIXTURE SCOPE AMPL BALANCE CHECK button. Check the trace shift after it returns to approximately CRT center: 1mm, max.

- i. Check vertical drift: 2mm, max
from 105VAC to 125VAC*

Note the trace drift while varying the line voltage from 105VAC to 125VAC: 2mm, max.

Return line voltage to 115VAC.

10. CRT CATHODE INPUT

- a. Remove CRT GND strap*

Loosen EXTERNAL CRT CATHODE and GND binding posts (scope rear) and swing strap away from EXTERNAL CRT CATHODE (strap must pivot around GND binding post).

- b. Check Intensity Modulation 20V*

Connect 20V SAC signal to EXTERNAL CRT CATHODE. Note that the trace is intensity modulated with the display at normal intensity. Remove SAC signal and replace ground strap.

11. AMPLITUDE CALIBRATOR*a. Setup*

Preset the test scope as follows:

VOLTS/CM	.5
VARIABLE VOLTS/CM	CALIBRATED
INPUT SELECTOR	A, AC

Connect the AMPLITUDE CALIBRATOR under test to the SAC/UNK IN connector. Connect the SAC OUTPUT through a coaxial cable to the TYPE B INPUT A. Set the SAC to +100V, DC MIXED. Set the AMPLITUDE CALIBRATOR under test to 100 VOLTS. Remove V875 from the instrument under test.

Trigger the test scope in AUTO, + LINE and set TIME/CM to 5mSEC.

Set the Cal Adj, R879 for a null voltage (the point where the display appears as a straight line).

b. Check .1 VOLTS position: $\pm 2\%$

*c. Check 50V to .2V position
observed error: $\pm 2\%$
observed error plus 1000:1 divider
error: $\pm 2\%$*

d. Check 50mV to .2mV operation

Replace V875 and check 50mV to .2mV positions for a squarewave of approximately the correct amplitude.

*e. Check calibrator frequency:
1 kHz $\pm 20\%$*

Set the SAC to UNKNOWN ONLY. Set the test scope TRIGGER SLOPE to + INT, and set the TIME/CM to 1mSEC. Set the test scope VOLTS/CM to .1. Check calibrator frequency 1 kc $\pm 20\%$ (8 to 12 cycles in 10cm).

*f. Check calibrator duty cycle: 45
to 55%*

Set the test scope TIME/CM switch to 50 μ SEC and adjust the VARIABLE for 1 cycle in 10cm. Check that 1/2 cycle is 4.5 to 5.5cm in duration. Return test scope VARIABLE to CALIBRATED.

b. If 100V is exactly 100V the error read in c is the divider error. If 100V is not adjusted to exactly 100V subtract algebraically the 100 VOLTS error (including sign) from .1 VOLT error (including sign) to find 1000:1 divider error (include sign).

b. Check the falling edge of the calibrator waveforms for rounding and the bottom of the waveform for 60 cycle hum.

12. TIME BASE TRIGGERING

- a. *Set TRIGGERING LEVEL mechanical zero: 0V*

Connect: SAC OUTPUT -- 50 Ω cable --
 BNC T -- Variable Atten -- TYPE 84 INPUT
 -- 50 Ω cable to TYPE 581A TIME BASE
 TRIGGER INPUT. Set TYPE 84 to
 EXT INPUT. Set TRIGGER SLOPE at + and
 TRIGGERING SOURCE to INT AC.

Connect meter to R14-R15 junction (on
 TRIGGERING SOURCE switch) and turn
 TRIGGERING LEVEL for zero volts on
 meter, use most sensitive meter range
 for final setting. Loosen TRIGGERING
 LEVEL knob set screw, position knob on
 shaft so white dot aligns with "0".
 Retighten set screw, making sure that
 TRIGGERING LEVEL remains at zero (watch
 the meter).

- b. *Adjust Trig Level Centering R25:
 + & - triggering on 1mm*

Set SAC to 2 VOLTS and adjust the
 Variable Atten for 2cm of vertical
 deflection. Change SAC to .1 VOLTS,
 and TIME/CM to .1mSEC.

Pre-adjust Trig Level Centering R26
 to midrange, and Trig Sens R47 near cw
 end. Ground R14-R15 junction.

Set test scope to .5mSEC, AUTO, + INT and
 .05 VOLTS, AC coupled. Connect the 10X
 probe to the junction of R41 and C45.
 Adjust Trig Level Centering R26 and Trig
 Sens R47 for a stable display of square-
 waves on test scope. Switch TRIGGER
 SLOPE switch between + & -, touch-up R26
 and R47 for stable + & - triggering.

- c. *Adjust Trig Sens R47: + & - triggering
 on 1/2mm, no triggering on 1/4mm*

Change SAC to 50mVOLTS, and adjust Trig
 Sens R47 (and Trig Level centering R26)
 for stable triggering + & -. Reduce
 signal amplitude to 1/4mm with the Variable
 Atten control and check that the TYPE 581A
 does not trigger. If the scope triggers
 readjust Trig Sens R47 so that the scope
 does not trigger on 1/4mm signal.

Remove the ground from R14-R15 junction.

- a. Allow sufficient clearance so
 the TRIGGERING LEVEL knob does
 not rub against the panel.
 Tighten the set screw securely
 enough to prevent the knob
 turning on the shaft, but not
 enough to cause the concentric
 shafts to bind.

12. (CONT)

- d. Check internal and external midrange triggering: 1 kHz, 2mm INT, 0.2V EXT
10 MHz, 2mm INT, 0.3V EXT
3mm INT HF SYNC, 0.2V EXT HF SYNC

TRIGGERING SOURCE	TRIGGERING LEVEL	SIGNAL 1 kHz	SLOPE	Signal Generator
INT AC	fixed	2mm	+ & -	SAC
LF REJ	variable	2mm	+ & -	SAC
EXT AC	variable	.2V P-P	+ & -	SAC
EXT DC	variable	.2V P-P	+ & -	SAC

Replace SAC and variable atten with TYPE 191

		10 MHz		
EXT DC	variable	.3V P-P	+ & -	TYPE 191
EXT AC	variable	.3V P-P	+ & -	TYPE 191
EXT HF SYNC	--	.2V P-P	+ & -	TYPE 191
INT AC	variable	2mm	+ & -	TYPE 191
LF REJ	variable	2mm	+ & -	TYPE 191
INT HF SYNC	--	3mm	±	TYPE 191

- d. In checking EXT trigger sensitivities use the test scope to set the amplitude of the TYPE 191. Set the amplitudes with the TYPE 191 RANGE SELECTOR in the 50 KC position.

13. LINE TRIGGERING

a. Setup

Remove the TYPE 191 and cables from the TYPE 84 and connect a 10X probe to the Variable Atten. Connect probe tip to 117 VAC at fuse holder. Set TIME/CM to 5mSEC and change TRIGGER SOURCE to LINE. Adjust the Variable Atten for a 4cm display.

b. Check triggering: correct slope

Check for correct triggering slope both + and -.

Set TIME/CM at 5mSEC and change TRIGGER SOURCE to LINE.

Check for correct triggering slope both + and -.

Remove probe from fuse holder and the Variable Atten.

14. PRESET ADJUST

a. Setup

TRIGGER SLOPE +
TRIGGERING SOURCE LINE
TIME/CM .1mSEC

Connect a multimeter between PRESET ADJUST center arm and ground.

b. Adjust PRESET ADJUST: center of range

Set STABILITY full ccw (PRESET). Turn PRESET ADJUST fully ccw, then slowly turn it cw until trace appears, note the meter reading. Continue turning cw until trace brightens and note meter reading. Set PRESET ADJUST halfway between the readings. Remove the meter.

b. PRESET ADJUST range

Range on preset between trace appearing and brightening should be approx 15 volts.

15. TRIGGERING LEVEL RANGE

a. Setup

Apply 20V squarewave from SAC to test scope through the Variable Attenuator. Adjust the Variable Attenuator for 15 volts as indicated on test scope.

b. Check TRIGGERING LEVEL range: 15V min

Move the Variable Attenuator to the TRIGGER INPUT. Set the TRIGGER SOURCE to EXT AC, STABILITY to PRESET and TIME/CM to 1mSEC.

Rotate the TRIGGERING LEVEL from cw to ccw and check that the sweep stops at the extremes.

16. MAGNIFIER GAIN

a. Setup

Connect the TYPE 184 MARKER OUT to the TYPE 84. Set TYPE 184 for 1ms and .1ms markers.

Turn 5X MAGNIFIER to ON. Set TRIGGERING SOURCE INT AC, TRIGGER SLOPE to + and set STABILITY and TRIGGERING LEVEL for a stable display.

a. Unless noted otherwise, use the middle 8 horizontal centimeters when making horizontal amplifier gain and timing checks or adjustments.

16. (CONT)

- b. *Adjust Mag Gain Adj R372: $\pm 3\%$
Magnified sweep linearity: $\pm 1\%$*

Adjust Mag Gain Adj R372 for two .1ms marks per cm at center of sweep. Check timing accuracy over entire sweep.
Error: $\pm 0.8\text{mm}$, max

- b. Sweep linearity

There should be no non-linearity that causes a timing change of greater than $\pm 1\%$ in any 8cm time window of the magnified sweep. The total timing error with MAGNIFIER ON must be 3% or less for all sweep rates (basic timing errors + errors caused by non-linearity of magnified sweep).

17. SWEEP CALIBRATION $\pm 2\%$

Change MAGNIFIER to OFF and adjust Swp Cal R348 for one lms mark per cm.

18. SWEEP LENGTH

Adjust Swp Length R176 for a trace length of 10.5cm.

19. NORMAL-MAGNIFIED REGISTRATION

$\pm 2\text{mm}$ at graticule center

Set 5X MAGNIFIER ON. Use HORIZONTAL POSITION controls to position the trace start at graticule center.

Switch MAGNIFIER OFF and adjust Norm Mag Regis, R358 to position trace start at graticule center. Switch MAGNIFIER ON to OFF and check that the trace start remains at the graticule center line $\pm 2\text{mm}$.

Set the 5X MAGNIFIER to OFF, and recenter the trace with HORIZONTAL POSITION control.

20. VARIABLE TIME/CM

- a. Check VARIABLE TIME/CM ratio:
2.5:1, min

Apply 1mS marks from the TYPE 184. Adjust the TRIGGERING LEVEL control for a stable display. Turn the VARIABLE TIME/CM control full ccw and check for at least 5 marks/2cm.

- b. Check neon: lit except in CALIBRATED

Check that the UNCALIBRATED neon is lit. Turn the VARIABLE TIME/CM cw, and check that the neon remains lit until the control actuates the CALIBRATED switch.

21. TIMING

- a. Check timing
.1mSEC-.5 SEC: $\pm 2\%$, max
1 and 2 SEC: $\pm 2.5\%$, max

Check the timing over the center 8cm of the graticule as in the following table:

TYPE 184			
TIME/CM	Markers	Marks/cm	Max error
.1mSEC	.1mS	1	1.6mm
.2mSEC	.1mS	2	1.6mm
.5mSEC	.5mS	1	1.6mm
1mSEC	1mS	1	1.6mm
2mSEC	1mS	2	1.6mm
5mSEC	5mS	1	1.6mm
10mSEC	10mS	1	1.6mm
20mSEC	10mS	2	1.6mm
50mSEC	50mS	1	1.6mm
.1 SEC	.1 S	1	1.6mm
.2 SEC	.1 S	2	1.6mm
.5 SEC	.5 S	1	1.6mm
1 SEC	1 S	1	2mm
2 SEC	1 S	2	2mm

- b. Adjust C330

Adjust TRIGGERING LEVEL and STABILITY as necessary. Change 5X MAGNIFIER to ON and TYPE 184 to 10 μ S. Switch TIME/CM back and forth between 50 μ SEC and .1mSEC and adjust C330 for coincidence of the first time mark.

21. (CONT)

- c. *Adjust and check timing:*
.05 μ SEC - 50 μ SEC: $\pm 2\%$, max
Magnified sweep: $\pm 3\%$, max
Linearity: $\pm 1\%$, max

TIME/CM	TYPE 184	Adjust	For
.05 μ SEC	10nS	C384	75% of range
.05 μ SEC	10nS	C364	75% of range
.05 μ SEC	10nS	C160A	1 cycle/cm
.05 μ SEC	10nS	C372	1 cycle/cm

Check C160A and C372 for interaction.

Check Mag on timing from 5th to 45th cycle for less than $\pm 3\%$ and linearity as in 17b. Turn 5X MAGNIFIER OFF.

T/CM	184	Adjust	Check for	Tolerance
.05 μ S	50nS	C348	1 cycle/cm	$\pm 2\%$
.1 μ S	.1 μ S	C160B	1 cycle/cm	$\pm 2\%$
.2 μ S	.1 μ S	C160B	2 cycle/cm	$\pm 2\%$
.5 μ S	.5 μ S	C160B	1 cycle/cm	$\pm 2\%$
1 μ S	1 μ S	C160C	1 cycle/cm	$\pm 2\%$
2 μ S	1 μ S	C160C	2 cycle/cm	$\pm 2\%$
5 μ S	5 μ S	C160C	1 cycle/cm	$\pm 2\%$
10 μ S	10 μ S	C160E	1 cycle/cm	$\pm 2\%$
20 μ S	10 μ S	--	2 cycle/cm	$\pm 2\%$
50 μ S	50 μ S	--	1 cycle/cm	$\pm 2\%$

Check the .1 μ S to 5 μ S 5X MAGNIFIER ON timing for $\pm 3\%$.

- c. Exclude all sweeps in excess of the first 50cm for any sweep rate faster than 50 μ s/cm.

C384, C364 and C160A are adjusted in the center of a magnified sweep. C372 is adjusted at center three divisions with sweep start set on 0 graticule line. Sweep start is found by increasing intensity.

Retiming with C384 timing short will indirectly lengthen the .5 μ S range in relation to .1 μ sec.

22. LOCKOUT LEVEL

- a. *Set Lockout Level: 9V to 11V*

Set the multimeter to the 300V scale and connect it between pin 8 of V133 and ground. Set the TYPE 581A TRIGGER SOURCE to +INT and TIME/CM to .1mSEC. Turn the STABILITY control ccw then cw to a point just before the trace appears. Note the voltage reading.

22a. (CONT)

Change the HORIZONTAL DISPLAY switch to SINGLE SWEEP. Adjust the Lockout Level, R125 for a reading of from 9V to 11V less than the first reading.

- b. *Check SINGLE SWEEP triggering: sweeps once on a triggering signal*

Set the HORIZONTAL DISPLAY to INTERNAL SWEEP. Connect the SAC to the Bandpass Plug-in INPUT. Set the controls for a 2mm display. Switch the HORIZONTAL DISPLAY to SINGLE SWEEP. Remove the SAC signal, press the RESET button. Check that the READY neon lights. Reconnect the SAC signal to the Bandpass Plug-in INPUT. Check that one sweep is produced, after which the READY neon goes out. Return the TYPE 581A HORIZONTAL DISPLAY to INTERNAL SWEEP.

23. + GATE INTERVAL AND FRONT PANEL WAVEFORMS

a. *Setup*

Remove the TYPE 184 signal. Set the test scope input coupling to DC and connect a 10X probe to the Vertical Input. Connect the probe tip to the + GATE binding post.

- b. *Check + GATE Interval: limits listed in table; Amplitude: 20V, min*

Check A & B + GATE Interval as listed in the table below. Change test scope TIME/CM, TRIGGERING LEVEL, and STABILITY control settings as necessary.

- b. The + GATE waveform with TIME/CM at 1mSEC and .05μSEC resemble the following illustration with the final portion flat.

	TIME BASE A
<u>TIME/CM</u>	<u>+ GATE Interval</u>
.05μSEC	3 to 9μs
.1μSEC	3 to 9μs
.2μSEC	3 to 9μs
.5μSEC	3 to 9μs
1μSEC	15 to 40μs
2μSEC	15 to 40μs
5μSEC	15 to 40μs

23b. (CONT)

<u>TIME/CM</u>	<u>TIME BASE A + GATE Interval</u>
10 μ SEC	15 to 40 μ s
20 μ SEC	15 to 40 μ s
50 μ SEC	15 to 40 μ s
.1mSEC	150 to 400 μ s
.2mSEC	150 to 400 μ s
.5mSEC	150 to 400 μ s
1mSEC	1.5 to 4ms
2mSEC	1.5 to 4ms
5mSEC	1.5 to 4ms
10mSEC	15 to 40ms
20mSEC	15 to 40ms
50mSEC	15 to 40ms
.1 SEC	150 to 400ms
.2 SEC	150 to 400ms
.5 SEC	150 to 400ms
1 SEC	150 to 400ms
2 SEC	150 to 400ms

c. Check SAWTOOTH OUT: >130V

Connect probe to the SAWTOOTH OUT jack and check for >130V sawtooth.

d. Check + GATE OUT: >20V

24. EXTERNAL HORIZONTAL

a. Adjust Ext Horiz DC Bal, R317:
 ± 1 cm max shift

Connect a jumper lead from SAWTOOTH OUT to TYPE 84 EXT INPUT thru the Variable Atten and switch the HORIZONTAL DISPLAY to EXT X1. Turn STABILITY cw. Center the vertical trace on the graticule.

Rotate the VARIABLE 10:1 control back and forth while adjusting Ext Horiz DC Bal, R317 for no trace shift. Leave the VARIABLE 10:1 control cw.

b. Check for grid current: ± 0.5 cm max shift

Connect a jumper to HORIZ INPUT. Connect the other end of the jumper to ground while watching the trace for a horizontal shift.

24. (CONT)

c. *Adjust C301C: X10 to X1 match $\pm 5\%$*

Connect a .5 VOLT SAC signal to the HORIZ INPUT and to TRIGGER INPUT. Set TIME/CM at .2mSEC, TRIGGER SLOPE at +, and TRIGGERING SOURCE at EXT AC. Adjust STABILITY and TRIGGERING LEVEL for a stable display. Adjust the Variable Atten for 1 complete cycle of squarewave. Check the waveform aberrations. Change the HORIZONTAL DISPLAY switch to EXT X10 and the SAC to 5 VOLTS.

Adjust C301C to match the X1 waveform $\pm 5\%$.

d. *Check external horizontal deflection factor: 0.2 VOLTS/CM max*

With the vertical trace displayed and the HORIZONTAL DISPLAY at EXT X1, switch the SAC to 1 VOLT. Check the X1 deflection for 5.0cm or more with the VARIABLE 10:1 cw.

e. *Check EXT X10 attenuation: divides X1 gain by 10 $\pm 2\%$*

Switch the SAC to 2 VOLTS and adjust the VARIABLE 10:1 for 8cm of horizontal deflection. Switch the HORIZONTAL DISPLAY to EXT X10 and switch SAC to 20 VOLTS and check for 8cm $\pm 2\%$.

f. *Check VARIABLE 10:1 ratio: 10:1 min*

Change the SAC to 10 VOLTS and change the HORIZONTAL DISPLAY to EXT X1. Turn the VARIABLE 10:1 ccw and note the deflection.

Switch the HORIZONTAL DISPLAY to EXT X10 and turn the VARIABLE 10:1 cw. The deflection is equal to, or greater than before.

g. *Check bandwidth: 350 kHz or more at -3dB*

Remove the SAC signal. Set the HORIZONTAL DISPLAY to EXT X1 and turn the VARIABLE 10:1 fully cw. Apply a 50 kHz signal from the TYPE 191; through a 50 Ω attenuator to the HORIZ INPUT. Adjust the TYPE 191 OUTPUT AMPLITUDE for exactly 4cm of horizontal deflection.

Without changing the TYPE 191 OUTPUT AMPLITUDE increase the frequency until the amplitude decreases to 2.8cm. Check the frequency for 0.35 MHz or more.

25. VERTICAL HF COMPENSATIONS*a. Setup*

Set TIME/CM at .2 μ SEC. Set the TYPE 84 LOAD to NORM and DISPLAY SELECTOR to PULSER. Adjust PULSER AMPLITUDE for a 2cm signal. Trigger scope for a stable display. Adjust FOCUS, ASTIGMATISM and INTENSITY for a sharp, waveform of min intensity. Vertically center the waveform.

b. Vertical amplifier presets

C1260 and C1261	near min capacity (slug out) located to rear of V1254
C1254 and C1214	near max capacity (slug in)
C1224, C1234 and C1244	mid r
C1276	near max capacity (located near rear vertical deflection plates)
R1293	about 10° from cw (located near front vertical deflection plates)
C1041 and C1042	near min capacity (slug out) located on V1044 tube socket

c. Recheck vertical gain: $\pm 2\%$ max

Connect PULSER AMPLITUDE OUT to UNKNOWN INPUT of the SAC. Set SAC AMPLITUDE to 50 volts, + DC MIXED and connect SAC OUTPUT to the test scope. Set TYPE 84 PULSER AMPLITUDE for exactly 50 volts.

Check the Vert Gain for exactly 2.0cm deflection.

d. Adjust C1209, C1006

With TIME/CM at .1 or .2 μ SEC and X5 MAGNIFIER ON, adjust C1209 (near V1214) and C1006 (front tube side of delay line driver stage) for best level and min aberrations.

d. Overall level

Check over-all level by periodically switching from fast to slow sweep speeds.

25. (cont'd)

e. Adjust C1214 thru C1254

Starting with C1214, adjust C1214 thru C1254 for best level and min aberrations.

f. Adjust C1260, C1261

Adjust C1260 and C1261 for a square corner and min aberrations.

g. Adjust R1293, C1276

Change TIME/CM to 1 or 2 μ SEC and adjust R1293 and C1276 for best overall level. Set TIME/CM to .05 μ SEC.

h. Check Vertical aberrations: Flatness $\leq 2\%$ P-P from 1mSec to .05 μ Sec

Most of the vertical hf adjustments interact, repeat as necessary to obtain a waveform with flat top and minimum aberrations: 0.4mm, max.

i. Selected R1204, C1204, R1205 and C1205

Select values of R1204, C1204, R1205, and C1205 (input of vert output stage) for no peaks or dip on 5 μ SEC and 50 μ SEC. Do not select parts untill all efforts to adjust for best waveform have been exhausted. Nominal values are 4 and .01 μ F. Present value limits are 2 to 7 Ω , 1/2W 1% and .1 to .005 μ F capacitors.

A rolloff or peak can usually be corrected by changing resistive elements, decreasing for a peak and increasing for rolloff. A hump or dip can usually be corrected by changing capacitive elements, decreasing for a hump and increasing for dip.

j. Check with side panel

Install the left side panel (cabinet, RM585A) or shield the output stage -- CRT deflection plate area. Recheck the front corner and overall level. It may be necessary to slightly readjust R1293.

f. C1260, C1261 -- ringing

Ringling will occur if C1260 and C1261 are not kept near min capacity.

*h. Adjustment of R1293 effects gain, therefore Vert Gain Adj R1015 must be rechecked.**i. Selected parts*

The selected parts provide compensation for mismatch in termination networks. The mismatch appears as a deviation from a flat top waveform behind the leading edge as observed at slower sweep speeds (.5 μ SEC and slower). Picking components often requires much trial and error before achieving success. Do not attempt unless aberrations are actually out of limits.

26. VERTICAL DELAY 40nsec, min

Set the TYPE 581A TIME/CM to .05 μ SEC.
Set 5X MAGNIFIER to ON.

Adjust TRIGGERING LEVEL so that rising portion of the waveform is 4cm or more from the sweep start. (40nsec or more)

27. VERTICAL BANDWIDTH*a. Setup*

Remove the TYPE 84 and install the Bandwidth Plug-In. Set the TYPE 581A TRIGGER SOURCE to INT HF SYNC.

Apply 20nS markers from the TYPE 184 to the Bandwidth Plug-In INPUT. Adjust the STABILITY and TRIGGERING LEVEL for a stable display. With the HORIZONTAL POSITION control near midr, check the timing accuracy over the full 10cm of the graticule. If the timing is short, note the amount. If the timing is long, use the VARIABLE TIME/CM to set it for exactly 5 cycles in 10cm.

Remove the TYPE 184 signal. Set the AMPLITUDE SET switch to AMPLITUDE SET, and the CONSTANT switch to CONSTANT VERTICAL IN BANDWIDTH. Set the TYPE 581A STABILITY control cw and adjust the Bandwidth Plug-In AMPLITUDE control for 2cm of vertical amplitude.

*b. Check Vertical Bandwidth: 95 MHz
or more at -3dB*

Set the AMPLITUDE SET switch to 50 to 100 MHz and adjust the FREQUENCY control for 1.4cm of vertical amplitude (-3dB). Adjust TRIGGERING LEVEL and STABILITY for a stable display. Check for 9.5 cycles or more in 10cm (95 MHz). Return VARIABLE TIME/CM to CALIBRATED.

28. HIGH FREQUENCY TRIGGERING

- a. *Check external HF triggering:*
 EXT 0.4V at 50 MHz; 1.2V 100 MHz;
 1.5V at 150 MHz; HF SYNC 0.2V at
 150 MHz

Connect 50Ω cable from Bandwidth Plug-In
 TRIG OUT to A TRIGGER INPUT. Use the
 following table to check External HF
 triggering. Set amplitude with the
 Bandwidth Plug-In at AMPLITUDE SET.

TRIGGERING SOURCE	amplitude	frequency	TRIGGER SLOPE
EXT AC	0.4V P-P	50 MHz	--
EXT DC	0.4V P-P	50 MHz	+ or -
EXT DC	1.2V P-P	100 MHz	+ or -
EXT AC	1.2V P-P	100 MHz	+ or -
EXT AC	1.5V P-P	150 MHz	+ or -
EXT DC	1.5V P-P	150 MHz	+ or -
EXT HF SYNC	0.3V P-P	150 MHz	+ or -

- A. Triggering frequency is read
 from the TYPE 581A display:
 50 MHz = 1 cycle/2cm
 100 MHz = 1 cycle/cm
 150 MHz = 3 cycles/2cm
 (TIME/CM .1μSEC, 5X MAGNIFIER ON)

Variable TRIGGERING LEVEL
 and STABILITY.

- b. *Check Internal HF triggering:*
 INT 1cm at 50 MHz; 2cm at 100 MHz;
 2.5cm at 150 MHz; HF SYNC 3mm at 150 MHz

Change the TYPE 581A TRIGGERING SOURCE
 to INT HF SYNC. Set the Bandwidth Plug-In
 CONSTANT switch to CONSTANT VERTICAL IN
 BANDPASS. Adjust the AMPLITUDE control
 for 2.5cm of 150 MHz signal. Check INT
 HF triggering using the following table.

TRIGGERING SOURCE	amplitude	frequency	TRIGGER SLOPE
INT HF SYNC	3mm	150 MHz	--
INT AC	2.5cm	150 MHz	+ or -
INT AC LF REJ	2.5cm	150 MHz	+ or -
INT AC LF REJ	2.0cm	100 MHz	+ or -
INT AC	2.0cm	100 MHz	+ or -
INT AC	1.0cm	50 MHz	+ or -
INT AC LF REJ	1.0cm	50 MHz	+ or -

Variable TRIGGERING LEVEL
 and STABILITY.

29. LOW FREQUENCY TRIGGERING

*Check LF triggering: INT 2mm 15Hz
 and 15kHz; EXT 0.3V 15Hz and 15kHz*

Install a BNC "T" connector on the INPUT
 of the Bandwidth Plug-In. Connect a 50Ω
 coax cable from the "T" connector to the
 TRIGGER INPUT.

Set TIME/CM switches to 50 μSEC
 when checking 15 kHz.

29. (cont'd)

Connect the output of the LFSWG to the "T" connector. Set TIME/CM switches to 50mSEC. Use the following table to check LF triggering. Check EXT triggering amplitude with test scope.

TRIGGERING SOURCE	amplitude	frequency	TRIGGERING SLOPE
INT AC	2mm	15 Hz	+ & -
INT AC	2mm	15 kHz	+ & -
INT AC LF REJ	2mm	15 kHz	+ & -
EXT AC and DC 0.3V P-P		15 Hz	+ & -
EXT AC and DC 0.3V P-P		15 kHz	+ & -

Variable TRIGGERING LEVEL.

SAMPLE CHECKS

[THE FOLLOWING CHECK IS NOT MADE ON 100% OF THE INSTRUMENTS BUT IS DONE ON A SAMPLING BASIS.]

I HF SYNC AT 250MHz INT 4mm; EXT 0.2V P-P

Connect the output of the CASG (067-0532-00) to bandpass plug-in INPUT.

Check INT HF SYNC with a 4mm display amplitude of 250 MHz.

Check EXT HF SYNC with a 0.2V P-P 250 MHz signal. Use 3 MHz amplitude reference to determine amplitude.

THE END